

# RENAULT

**N.T. 3247A**

---

**XXXX**

---

**Belt tension using tool Mot. 1505**

**This note contains:**

- **a presentation of the new tool for measuring belt tension Mot. 1505,**
- **the procedure for using the tool,**
- **recommendations for fitting timing belts and accessories belts,**
- **tension values (SEEM units/Hertz).**

**A Technical Note will be issued later to show the tension values (in Hertz) for accessories belts on C - G - J - S and Z engines.**

## Contents

	Page
<b>07</b> <b>VALUES AND SETTINGS</b>	
Belt tension	07-1
Timing belt tension	07-5
Accessories belt tension	07-12
<b>D engine</b>	07-13
<b>E and K engines</b>	07-15
<b>F engine</b>	07-20

---

# VALUES AND SETTINGS

## Belt tension


07

### IMPORTANT

The procedure for tensioning a belt is an important operation since it determines the length of the belt's life.

The use of the frequencymeter Mot. 1505 is therefore essential in order to apply the correct fitting tension in accordance with the manufacturer's recommendations and to eliminate the risk of overtensioning (or undertensioning), noise and problems resulting from incorrect belt tensioning.

If this tensioning procedure using Mot. 1505 is not strictly observed, the engine may be damaged.



- A Reading head with two sensors (a) and (b)
- B Display unit
- C Standard frequency generator ( $512 \pm 1$  Hertz) integral in display unit
- D Equipment on/off button
- E Test button to check the unit is correctly calibrated
- F Instructions for the equipment

### OPERATING PRINCIPLE

This equipment measures the frequency of the belt.

The frequency is a physical value which in this instance reflects the belt tension level with a high degree of accuracy.

The units used are **Hertz (Hz)**.

The reading head (A) comprises two sensors (a) and (b) which measure the vibrations in the belt after it has been moved.

Measurement takes place using only one sensor, as the other sensor is for reference purposes and must be outside the measuring area (see instructions).

Each of the sensors may be used as either a measuring sensor or a reference sensor.

### SPECIFICATIONS

Measuring range: **30 to 520 Hz**

Accuracy:  **$\pm 1 \text{ Hz} < 100 \text{ Hz}$  and  $\pm 1 \% > 100 \text{ Hz}$**

### CHECKING THE EQUIPMENT

The standard frequency generator (C) integrated in the display unit allows the correct operation of the equipment to be checked.

Refer to the instructions for the checking procedure.

If the value read on the two sensors differs by more than  **$512 \pm 1 \text{ Hz}$** , the equipment must be returned to SEEM.

Refer to your After Sales Head Office for further details.



### USING THE EQUIPMENT

Turn the equipment on (button D) and bring the measuring head (A) up to the part of the belt to be measured.

Position the measuring head at distance (X) approximately 5 to 10 mm from the belt.

Measurements can be taken on either side (1) or side (2) of the belt, depending on which gives better access.


Sensor (a) or sensor (b) may be used, as long as the sensor being used for reference purposes is out of the measuring area.



# VALUES AND SETTINGS




## Belt tension

Both sensors may not be opposite the belt at the same time when the measurement is taken.



The measurement is taken by vibrating the belt using your finger.

The measurement is complete when a beep is heard.



### INSTRUCTIONS FOR FITTING TIMING BELTS

Depending on the family of engine, there are three separate procedures which must be observed:

Certain engines require:

- pretensioning (using a specific tool depending on the engine type) of the section of belt to be measured in order to compensate for all play relative to the belt
- pretensioning T1 slightly above the final fitting tension T2.

Both of these operations aim to stabilise the internal tension of the belt in order to give a reliable tension measurement.

### TENSIONING PROCEDURE

#### J engines, all types (no pretensioning)

Engine cold, ambient temperature.

Fit the new belt, with the timing at the setting point (TDC).

Set the tension wheel against the belt using tool **Mot. 1135-01** or tool **Mot. 1384** depending on the type of tensioner and tension the belt to obtain the recommended fitting tension.

Lock the tension wheel.

Turn the crankshaft four times and reposition the timing at TDC.

Position the reading head of tool **Mot. 1505** and carry out the measurement, check if it is in the fitting tension tolerance range, otherwise adjust it using the tool for adjusting the tension wheel.

Torque tighten the tension wheel nut.

**NOTE :this procedure is only valid for engines fitted with a dynamic tension wheel. For tensioners with a spring just check the fitting tension after fitting the tensioner.**

#### D - E and K7M engines (with pretensioning)

Engine cold, ambient temperature.

Fit the new belt, with the timing at the setting point (TDC).

Set the tension wheel against the belt using tool **Mot. 1135-01** and tension the belt to obtain the recommended fitting tension.

Lock the tension wheel.

Pretension using the special tool (**Mot. 1386** for D engines and tool **Mot. 1501** for E engines and K7M), using a torque wrench **set to a torque of 1 daN.m**, on the part of the belt to be measured (refer to the belt diagrams below).

Position the reading head of tool **Mot. 1505** and carry out the measurement, check if it is in the fitting tension tolerance range, otherwise adjust it using **Mot. 1135-01**.

Lock the tension wheel.

Turn the crankshaft four times and reposition the timing at TDC.

Pretension using the special tool (**Mot. 1386** for D engines and tool **Mot. 1501** for E engines and K7M), using a torque wrench **set to a torque of 1 daN.m**, on the part of the belt to be measured (refer to the belt diagrams below).

Check the tension value is in the fitting tension tolerance range, otherwise readjust it by repeating the procedure.

Torque tighten the tension wheel nut.



**F engine, all types  
(with and without pretensioning)**

Engine cold, ambient temperature.

Fit the new belt, with the timing at the setting point (TDC).

Set the tension wheel against the belt by tightening a bolt on the inner timing cover.

Pretension using the special tool (**Mot. 1543-02** with intermediate shaft and **Mot. 1543-03** without intermediate shaft), using a torque wrench **set to a torque of 1.1 daN.m**, on the part of the belt to be measured (refer to the belt diagrams below).

Position the reading head of tool **Mot. 1505**, carry out the measurement, then adjust the tension using the bolt against the tension wheel to obtain the **pretension value T1**.

Lock the tension wheel.

Turn the crankshaft four times and reposition the timing at TDC.

Pretension using the special tool, using a torque wrench **set to a torque of 1.1 daN.m**, on the part of the belt to be measured (refer to the belt diagrams below).

Position the reading head of tool **Mot. 1505**, carry out the measurement, then adjust the tension using the bolt against the tension wheel to obtain the **pretension value T2**.

**NOTE : do not re-use a belt once it has been removed - RENEW IT.**

# VALUES AND SETTINGS

## Timing belt tension

07

ENGINE TYPE	FITTING TENSION IN SEEM UNITS	MINIMUM OPERATING TENSION IN SEEM UNITS	FITTING TENSION IN HERTZ
<b>D7F</b>	20	10	*
<b>E5F</b> 710 - 716 <b>E6J</b> 700 - 701 - 706 - 707 - 712 - 713 - 718 - 734 - 738 - 742 - 745 - 760 - 761 - 790 - 791 <b>E7F</b> 700 - 704 - 706 - 708 - 730 - 750 <b>E7J</b> 601 - 700 - 706 - 707 - 710 - 711 - 716 - 717 - 718 - 719 - 720 - 724 - 726 - 728 - 742 - 745 - 754 - 756 - 757 - 764 - 770 - 771 - 773 - 790 - 791 <b>K7M</b> 702 - 703 - 790	30	26	144±5
<b>E7J</b> 780 <b>K7M</b> 704 - 720 - 744 - 745	30	26	162±5
<b>F8M</b> 700 - 720 - 730 - 736 - 760	41	37	T1 = 68±3 T2 = 61±5
<b>F8M</b> 700 - 720 - 730 - 736 - 760 <b>F8Q</b> 610 - 620 - 706 - 710 - 740 - 742 - 744 - 764 - 766 - 768 - 784	38	36	
<b>F8Q</b> 640 - 646 - 676 - 678 - 714 - 722 - 724 - 730 - 732 - 774	28	25	
<b>F8Q</b> 630 - 640 - 644 - 646 - 648 - 662 - 676 - 678 - 680 - 682 - 684 - 714 - 730	47	36	
<b>F8Q</b> 600 - 606 - 620 - 624 - 784 - 786 - 788	47	36	
<b>F9Q</b> 716 - 720 - 730 - 731 - 734 - 736	T1 = 42 T2 = 37	36	
<b>F1N - F2N - F3N - F3P</b>	25	22	T1 = 91±3 T2 = 82±5
<b>F3R</b>	29	27	T1 = 83±3 T2 = 77±5
<b>F7P - F7R</b>	32	19	74±7

\*The tension values in **Hertz** for these engines will be available in the next update.

# VALUES AND SETTINGS

## Timing belt tension


07

ENGINE TYPE	FITTING TENSION IN SEEM UNITS	MINIMUM OPERATING TENSION IN SEEM UNITS	FITTING TENSION IN HERTZ
<b>852</b> <b>J8S</b> (all types except J8S 760)	45	26	*
<b>J8S 760</b>	50	26	104±4
<b>J7R 752 - 756</b>	41	31	*
<b>J5R - J6R -</b> <b>J7R</b> (all types except J7T 752 - 756)	39	26	73±4
<b>J7T</b>	36	24	69±4
<b>8144 -S8U 762</b>	45	28	*
<b>N7Q - N7U</b>	Automatic tensioner	Check between 36 and 46	-
<b>L7X</b>	83±2	-	*
<b>F4P - F4R - F5R</b> <b>G8T</b> <b>K4M - K4J</b> <b>S8U</b> (all types except S8U 762) <b>S9U - S9W</b>	Automatic tensioner	-	-


\*The tension values in **Hertz** for these engines will be available in the next update.

Diagram of timing belts showing points for measurement and for pretensioning using the special tool.

### D7F engine




### F8M - F8Q - F9Q engines




\* Mot. 1543-02 with intermediate shaft  
 Mot. 1543-03 without intermediate shaft

### E and K7M engines




### F1N - F2N - F3N - F3P - F3R engines



\* Mot. 1543-02 with intermediate shaft  
 Mot. 1543-03 without intermediate shaft


- Point for pretensioning and/or checking belt tension
- Point for applying pretensioning tool

### F7P - F7R engines



\* Mot. 1543-02 with intermediate shaft  
 Mot. 1543-03 without intermediate shaft


### 852 - J8S engines




➡ Point for pretensioning and/or checking belt tension

⬛ Point for applying pretensioning tool


### J5R - J6R - J7R - J7T engines



### 8144 - S8U 762 engines



N7Q - N7U engines



➡ Point for pretensioning and/or checking belt tension

### INSTRUCTIONS FOR FITTING ACCESSORIES BELTS

#### TRAPEZOIDAL BELT

- **Procedure for tensioning a new belt**

Engine cold, ambient temperature

Fit the new belt.

Set the tension wheel against the belt and tighten to obtain the recommended fitting tension.

Lock the tension wheel.

Turn the crankshaft **three times**.

Position the reading head of tool **Mot. 1505** and carry out the measurement, check to see if it lies **in the fitting tension tolerance range, otherwise readjust it.**

- **Procedure for tensioning a belt which has been used**

Engine cold, ambient temperature

Fit the belt.

Set the tension wheel against the belt and tighten to obtain **80 % of the recommended fitting tension value.**

Lock the tension wheel.

Turn the crankshaft **three times**.

Position the reading head of tool **Mot. 1505** and carry out the measurement, check to see if it lies **in 80% of the fitting tension tolerance range, otherwise readjust it.**

**NOTE :** the trapezoidal belt is replaced **according to condition or noise.**

#### RIBBED BELT

- **Procedure for tensioning the belt**

Engine cold, ambient temperature

Fit the new belt.

Set the tension wheel against the belt and tighten to obtain the recommended fitting tension.

Lock the tension wheel.

Turn the crankshaft **three times**.

Position the reading head of tool **Mot. 1505** and carry out the measurement, check to see if it lies **in the fitting tension tolerance range, otherwise readjust it.**

**NOTE :** **DO NOT RE-USE A BELT ONCE IT HAS BEEN REMOVED- RENEW IT.**





## 4 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
D7F 700 - 701 - 702 - 706 - 710 - 720 - 722 - 730	Alternator	102±7	53	244±5	1

## 5 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
D7F 702 - 722	Alternator Power assisted steering	96±5	43	177±5	2
D7F 700 - 701 - 702 - 720	Alternator Air conditioning	104±6	56	191±5	3
D7F 720	Alternator Power assisted steering Air conditioning	101±6	51	180±4	4





- A Crankshaft
- B Alternator
- C Power assisted steering pump
- D Air conditioning compressor
- G Pulley
- T Tension wheel
- Point for checking tension

## Accessories belt tension

## TRAPEZOIDAL BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
<b>E5F</b> 710 - 716 <b>E7J</b> 601 - 700 - 706 - 707 - 710 - 711 - 716 - 717 - 718 - 719 - 720 - 724 - 728 - 742 - 745 - 754 - 773 <b>E7F</b> 700 - 704 - 706 - 708 - 730 - 750 <b>E6J</b> 700 - 701 - 706 - 712 - 713 - 718 - 734 - 738	Alternator	83±7	70	237±10	1
<b>E6J</b> 700 - 701 - 706 - 707 - 742 - 745 - 790 - 791	Air conditioning	90±6	72	143±5	2

## 3 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
<b>E5F</b> 710 - 716 <b>E6J</b> 700 - 701 - 706 - 712 - 713 - 718 - 734 - 760 - 761 <b>E7J</b> 601 - 700 - 706 - 707 - 710 - 711 - 716 - 717 - 718 - 719 - 720 - 724 - 728 - 742 - 745 - 754 - 773 - 790 - 791 <b>E7F</b> 704 - 708 - 750 <b>K7M</b> 702 - 703 - 720	Alternator	84±6	52	263±10	1
<b>E7J</b> 780 <b>K7M</b> 744 - 745	Alternator	101±6	52	161±9	3
<b>E7J</b> 764 <b>K7M</b> 702 - 703 - 720 - 790	Alternator Power assisted steering	84±6	52	186±9	4

## Accessories belt tension




## 4 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
<b>E5F</b> 710 - 716 <b>E6J</b> 712 - 718 - 760 <b>E7F</b> 704 - 706 - 708 - 750 <b>E7J</b> 601 - 710 - 711 - 718 - 719 - 754	Alternator Air conditioning	103±4	77	141±7	5
<b>E6J</b> 734 <b>E7J</b> 720 - 724 - 726 - 728 - 773	Air conditioning	102±6	55	222±10	6
<b>E6J</b> 712 - 713 - 718 - 734 - 760 - 761 <b>E7J</b> 601 - 710 - 711 - 717 - 718 - 719 - 720 - 724 - 726 - 728 - 754 - 756 - 757 - 770 - 771 - 773	Air conditioning Power assisted steering	110±7	75	222±8	7
<b>E6J</b> 700 - 701 - 706 <b>E7J</b> 700 - 707 - 710 - 742 - 745 - 764 - 790 - 791 <b>K7M</b> 702 - 703 - 720 - 790	Air conditioning Power assisted steering	106±5	59	174±9	8
<b>E7J</b> 780 <b>K7M</b> 744 - 745	Power assisted steering	106±6	59	189±9	9


## 5 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
<b>K4M</b> <b>K4J</b>	Alternator Power assisted steering	108±6	60	190±10	10





## Accessories belt tension





\* Checking point only to be used for SEEM tool  
Mot. 1273



- A Crankshaft
- B Alternator
- C Power assisted steering pump
- D Air conditioning compressor
- G Pulley
- T Tension wheel
- Point for checking tension



- A Crankshaft
- B Alternator
- C Power assisted steering pump
- D Air conditioning compressor
- G Pulley
- T Tension wheel
- Point for checking tension



- A Crankshaft
- B Alternator
- C Power assisted steering pump
- D Air conditioning compressor
- G Pulley
- T Tension wheel
- Point for checking tension

## 5 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
<b>F1N</b> 720 - 722 - 724 <b>F2N</b> 702 - 712 - 716 - 720 - 721 - 724 - 726 - 727 - 728 - 754 - 758 - 770 <b>F3N</b> 722 - 726 - 740 - 741 - 742 - 743 <b>F3P</b> 704 - 706	Alternator Water pump	94±5	60	172±5	1
<b>F8M</b> 720 - 730 - 736 - 760	Alternator Water pump	109±7	72	161±5	1

## 6 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
<b>F8M</b> 730	Alternator Water pump	118±6	83	161±5	1
<b>F8M</b> 730	Alternator Power assisted steering	104±6	71	165±5	2
<b>F1N</b> 722 - 724 <b>F2N</b> 720 - 721 - 726 - 727 - 754 - 758 - 786 - 798 <b>F3N</b> 722 - 726 - 740 - 741 - 742 - 743 - 746 <b>F3P</b> 704 - 706 - 708 - 710 - 712 - 714 - 758 - 760	Alternator Water pump	83±6	57	120±5	1
<b>F2N</b> 720 - 721 - 726 - 727 - 754 - 758 - 786 <b>F3N</b> 722 - 723 - 740 - 741 - 742 - 743 - 746 <b>F3P</b> 682 - 700 - 704 - 705 - 706 - 707 - 760 - 764 - 765	Alternator Power assisted steering	98±6	73	150±5	2





## 6 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
<b>F3P</b> 710 - 712 - 714 - 754 - 755 - 758	Alternator Water pump Power assisted steering	94±5	60	290±5	3
<b>F3R</b> 750 - 751 - 752	Alternator Water pump Power assisted steering	107±3	62	173±5	2
<b>F3P</b> 678 - 720 - 724 <b>F3R</b> 722 - 723	Alternator Water pump Power assisted steering	107±3	62	132±5	4
<b>F2N</b> 716 - 720 - 721 - 724 - 726 - 754 - 758 - 786 <b>F3N</b> 740 - 741 - 742 - 746	Alternator Air conditioning	112±8	59	130±5	4
<b>F3P</b> 710 - 712 - 714 - 754 - 755 - 758	Alternator Air conditioning	104±7	55	261±5	3
<b>F2N</b> 720 - 721 - 726 - 727 - 754 - 758 - 786 <b>F3N</b> 722 - 723 - 742 - 743 - 746 <b>F3P</b> 682 - 684 - 700 - 704 - 705 - 706 - 707 - 708 - 760 - 764 - 765	Alternator Air conditioning Power assisted steering Water pump	106±6	71	143±5	5
<b>F3P</b> 670 - 678 - 720 - 724 <b>F3R</b> 722 - 723 - 728 - 729 - 742 - 750 - 751 - 752 - 769 - 791 - 796 - 797 - 798	Alternator Air conditioning Power assisted steering Water pump	109±3	62	132±5	5
<b>F7P</b> 700 - 704 - 722	Alternator Power assisted steering	95±5	57	155±5	6
<b>F7P</b> 704 - 720 - 722 <b>F7R</b> 700	Alternator Power assisted steering	111±6	64	319±5	7
<b>F7R</b> 704	Alternator Air conditioning	91±5	58	169±5	2





## 6 TOOTH RIBBED BELT

ENGINE TYPE	BELT FUNCTION	FITTING TENSION SEEM UNITS	MINIMUM OPERATING TENSION SEEM UNITS	FITTING TENSION HERTZ	DIAGRAM
<b>F8Q</b> 620 - 706 - 710 - 740 - 742 - 744 - 764 - 766	Alternator	97±3	67	134±5	1
<b>F8Q</b> 630 - 640 - 644 - 464 - 672 - 676 - 678 - 714 - 718 - 722 - 724 - 730 - 732 - 774 - 776 - 778	Alternator	106±4	74	127±5	1
<b>F8Q</b> 610 - 710 - 740 - 742 - 744 - 764 - 766 - 768	Alternator Power assisted steering	99±5	68	165±5	2
<b>F8Q</b> 610 - 740 - 744 - 768	Alternator Air conditioning	101±5	67	145±5	2
<b>F8Q</b> 706 belt Part No.: 77 00 271 648	Alternator Air conditioning Power assisted steering Water pump	112±4	67	164±5	8 or 9
<b>F8Q</b> 706 belt Part No.: 77 00 272 741	Alternator Power assisted steering Water pump	116±7	67	164±5	8
<b>F8Q</b> 630 - 662	Alternator Power assisted steering Water pump	104±5	62	174±5	6
<b>F8Q</b> 620 - 624 - 784 - 786 - 788 <b>F9Q</b> 716 - 720 - 734	Alternator Power assisted steering Water pump	109±7	68	188±5	2
<b>F8Q</b> 630	Alternator Air conditioning Water pump	115±7	82	177±5	2
<b>F4P</b> <b>F4R</b>	Alternator Power assisted steering Water pump	102±6	48	175±5	2





\* Checking point only to be used for SEEM tool  
 Mot. 1273


- A Crankshaft
- B Alternator
- C Power assisted steering pump
- D Air conditioning compressor
- E Water pump
- G Pulley
- T Tension wheel
- Point for checking tension



\* Checking point only to be used for SEEM tool  
Mot. 1273



- A Crankshaft
- B Alternator
- C Power assisted steering pump
- D Air conditioning compressor
- E Water pump
- G Pulley
- T Tension wheel
- Point for checking tension



- A Crankshaft
- B Alternator
- C Power assisted steering pump
- D Air conditioning compressor
- E Water pump
- G Pulley
- T Tension wheel
- Point for checking tension